

## Mailbox Support Diagram

[Return](#)

This diagrams show proper mailbox support setup.

### List of Materials for One Mailbox Setup

- 1 - one-half inch thick wood filler cut to fit snug under the mailbox
- 1 - 5 foot sign post (3 lbs./foot)
- 1 - bottom half of mailbox support
- 1 - top half of mailbox support

### Notes:

- All pipes and pipe fittings shall conform to spec. 3362
- All fasteners shall conform to spec. 3391
- All materials shall be galvanized per spec. 3392
- Mailbox locations should be staked before installation for proper height and distance from the roadway. Once staked, the installer must notify the engineer. The engineer will be allowed 48 hours to review and modify the staked locations prior to final installation.
- Sherburne County will supply the complete mailbox support  
Install existing mailboxes on new supports.
- The mailbox to be 6 to 12 inches outside the edge of the shoulder or 6 to 12 inches from the face of the curb.
- No more than three mailboxes spaced 30 inches center to center are to be used in one location.

[Return](#)